




PLAYBACK

- Right click with the mouse and enter your 'user' password (or pattern) to access the menu (ensure the onscreen keyboard drops back down to lower case when required)
- Left click on the 'Playback' icon from the top menu bar at the top of the screen
- Check/tick one or more cameras from the camera selection to start playing the associated footage
- Double click a date in the calendar to start playing the footage for that date
- To play from a specific time, left click and hold the drag bar at the bottom of the screen then release when you get to your desired start time.
- Click the relevant camera in the channel(s) section to execute simultaneous playback of multiple cameras.




Download/Export

To download or export images or video footage from the unit, you can create a clip (quickest method), select a time and date period, or attach tags to the required start and end time then download the tagged video period.

Creating a Clip

- Follow the previous instructions to identify the correct camera and time and date required.

- At the bottom of the screen, you will see the clipping tool icon (a small icon which looks like pair of scissors)



- Click this icon then click the scissors in brackets icon
- Now enter your start date & time and end date & time
- Click export then choose the device (USB memory stick) you are exporting to from the 'device name' list. If you have subfolders on your device, select the subfolder where you wish to save this footage then press OK to start the download/export
- To check the progress of the download/export, return to the live screen view then click on the 'backup' icon at the top right of the screen.